

Crank Standing Desk :

MOQ:1SET.

Trade Items:EXW,FOB,C&F,CIF,DDU,DDP.

MOQ	1.Sample order are welcomed 2.FOB/CIF: one 20 GP' at least . 3.mixed models are acceptable
Trade Terms	EXW ,FOB,CIF,CFR
Port	Shanghai,Ningbo
Payment Terms	1.T/T:30% repaid in advance,pay off the balance before loading 2.L/C:irrevocable L/C at sight are acceptable.
Lead time	1. stock goods can be delivered 3-7days. 2. New-production:7-20 days after receiving the 30% deposit.
Warranty	Any defect under proper using during warranty 24 months from purchasing date ,we will be responsible to repair or replace new parts , but not including any freight .
Remarks	1.OEM or ODM service and customized orders are available. 2.Less Than Container orders can be acceptable. You can tell us your trust agency in China to arrange the transport or ask them call us. 3.VAT invoice are available. You can negotiate with us about the prices

Crank Standing Desk Pictures:






Package Details:





WS5 series crank adjustable desk




WS5 series using instruction





Installation Instruction:

WS5 series crank adjustable desk



WS5 series using instruction

installation instruction



left leg 1pc




right leg 1pc




level beam 1pc



U tube 1pc



side frame 1pc



base 2pcs



hexangular



crank hand pc



M10X25 screw 4pcs



adjustable pad





M8X25 screw




MBX25 screw


Parts




step 1, loose the screw, adjust the leg vertical




Step 2, loose the screw M10X25 , then input "U" shape tube ,adjust to the demand height .



step 3, install the side frame (as picture) .



Step 4, use M8X25 screw fixing the base and adjus the height with pad(see



Step 5, Adjust the hexangular beam to the required length.

Contact Us

Alice Zhang

Tel:+86-512-66212961

Ph/Whatsapp:+86-13812623891

Email: Sales2@houdry.com.cn

